



## Club Car Precedent Installation Instructions

Technical Support  
1-800-365-1559



**CAUTION: WEAR APPROPRIATE  
EYE PROTECTION!**

### Side Track Installation:

- 1) Remove windshield and any accessories attached to the front canopy supports.
- 2) Remove the front bolts that attach the front supports to canopy. Hardware will not be reused.
- 3) Using the hardware included, mount the Long Side Rail with the C Channel facing outward. Place one 3/4" spacer between the canopy forward mounting bolt and the C Channel. (See PHOTO #1)  
Also on the rear of Long Side Rail add a 1/2" spacer on the forward mounting bolt (See Photo #2).
- 4) Tighten the hardware.
- 5) Repeat steps 1 through 4 on the opposite side of the car.

### Rear C Channel Installation:

- 1) Using the rear Short aluminum C Channel as a guide, mark and drill three 3/16" holes in the canopy 18" protrusion (PHOTO #3).
- 2) Install the rear C Channel to the inside of 18" protrusion using the supplied screws and nuts. (PHOTO #3)  
Note: the C Channel faces outward toward rear of car.

### Enclosure installation:

- 1) Remove the sleeve from the enclosure and wrap the sleeve around the canopy supports so the windshield retention clip cutout is in the proper position for the windshield to clip into place.
- 2) Engage the smaller zipper so that it wraps snugly around the canopy supports. The zipper should be on the inner side of the canopy supports. (See PHOTO #4)
- 3) Install rear and side panels of the enclosure by sliding them into the bottom C Channel of the aluminum rail. Tuck the bottom curtain edge (rear) and side panel curtain under the seat bottom. (See PHOTO #5&6)
- 4) Attach the sleeve to the enclosure, adjusting the height of the sleeve as necessary for even alignment with the enclosure zipper.
- 5) Attach the windshield by carefully snapping the windshield extrusions around the sleeve and canopy supports. Tech Tip: Do not force the extrusions into place. Start at the bottom of each extrusion and push inward a little at a time until in place.

**Valance Installation:** Select the desired color and slide into the top C Channel. Snap the valance to the enclosure and place decorative plugs into the ends of the C Channels. (PHOTO #7)

# Chameleon Installation Photos



Canopy Support  
Wrap

Photo #4



Side C Channel  
Front Spacers

Photo #1

Edging Tucked



Photo #5



Side C Channel  
Rear Spacer

Photo #2

Enclosure On  
Car



Photo #6



Rear  
C Channel Rail

Photo #3

Plugs



Photo #7